



## JPG-800

NO.	CODIGO	DESCRIPCION	Cantidad
1	DH-137	CUBREVENTILADOR	1
2	DH-046	CHECK RING	1
3	DH-138	VENTILADOR	1
4	DH-139	TAPA POSTERIOR	1
5	DH-085	ARO	1
6	DH-140	TORNILLO	4
7	DH-141	CARCASA MOTOR	1
8	DH-142	STATOR	1
9	DH-019	RODAMIENTO 6201-2RS	1
10	DH-143	ROTOR	1
11	DH-100	RODAMIENTO 6201-2RS	1
12	DH-144	PROTECTOR	1
13	DH-134	CONDENSADOR 16 MF	1
14	DH-145	TORNILLO	2
15	DH-146	FIJACION CABLE	1
16	DH-147	PROTECTOR CABLE	1
17	DH-148	MONOFASICA	1
18	DH-149	CAJA CONEXIONES	1
19	DH-150	TORNILLO	4
22	DH-151	INTERRUPTOR	1
23	DH-152	TORNILLO	2
24	DH-153	ASA	1
26	DH-032	TUERCA	4
27	DH-154	BASE	1
28	DH-155	TORNILLO	2
29	DH-156	TAPA FRONTAL	1
30	DH-157	ANILLO	1
31	DH-158	JUNTA TORICA	1
32	DH-159	CUERPO CIERRE	1
33	DH-160	SELLO MECANICO	1
34	DH-161	RODETE	1
35	DH-162	DIFUSOR	1
36	DH-163	JUNTA TORICA	1
37	DH-164	VENTURI	1
38	DH-165	JUNTA TORICA	1
39	DH-166	CUERPO BOMBA	1
40	DH-167	TORNILLO	4

## JPG-800

NO.	CODIGO	DESCRIPCION	Cantidad
41	DH-168	ARANDELA	4
42	DH-169	TAPON	2
43	DH-170	JUNTA TORICA	2
44	DH-171	TORNILLO	2
49	DH-172	TORNILLO	2
50	DH-173	SOPORTE INTERRUPTOR	1
51	DH-174	TAPA CAJA CONEXIONES	1